# GENERAL INFORMATION




**INTRODUCTION** ..... 1

**WEIGHT RESTRICTIONS** ..... 3

- Regulations and Requirements ..... 3
- Gross Axle Weight Rating ..... 3
- Weighing the Vehicle ..... 3
- Tire Inflation ..... 3
- Center of Gravity ..... 3

**INSTALLATION OF BODY AND SPECIAL EQUIPMENT** ..... 4

- Clearance Around Engine, Driveline and Others ..... 4
- Engine ..... 4
- Transmission ..... 4
- Front and Center Propeller shafts ..... 4
- Rear Propeller Shaft ..... 5
- Exhaust System Clearance ..... 5
- Rear Wheel and Axle Clearance ..... 5
- Other Clearances ..... 5
- Body Installation ..... 6
- Installation of Special Equipment on the Chassis ..... 6
- Subframe Design and Mounting ..... 6
- Contouring of Subframe ..... 6
- Prohibited Attachment Areas ..... 7
- Subframe Mounting Bracket Installation ..... 7
- Subframe Mounting U-bolt Installation ..... 7
- Modification of the Chassis Frame ..... 8
- Working on Chassis Frame ..... 8
- Drilling and Welding ..... 8
- Reinforcement of Chassis Frame ..... 8
- Welding ..... 9
- Fluid Lines ..... 9
- Preparation of Additional Lines ..... 9
- Installation of Additional Lines ..... 9
- Electrical Wiring and Harnessing ..... 10
- Wiring ..... 10

**WIRE COLOR CODE** ..... 12

- Maximum Current Allowable in Low Voltage Wiring ..... 12
- Exhaust System ..... 12
- Fuel System ..... 12
- Rear Comb. Lamp/License Plate Lamp Mounting Bracket ..... 12
- Serviceability ..... 13

**Wheelbase Alteration** ..... 13

**Shortening/Lengthening the Wheelbase without Altering the Frame** ..... 13

**Altering the Wheelbase by Altering the Frame** ..... 13

**Glossary of Terms–Chassis Wheelbase Alteration** ..... 13

**1999 MODEL YEAR BODY APPLICATION SUMMARY CHART** ..... 17

**1999 MODEL YEAR* BODY & PAYLOAD WEIGHT DISTRIBUTION (% FRONT/% REAR)** ..... 18

**1999 GM/ISUZU SERIES TRUCK PRODUCT ENGINES** ..... 20

**GVW/GCW Ratings** ..... 20

**Clutch Engagement Torque Chart** ..... 21

**PAINT CODE NUMBERS FOR 1987–1995 W3500/W4500** ..... 22

**PAINT CODE NUMBERS FOR 1995.5–1999 W3500/W4500** ..... 23

**PAINT CODE NUMBERS FOR 1997–1998 F SERIES MODELS (ZY1 PAINT SCHEME)** ..... 23

**W3500, W4500, W5500 TOWING PROCEDURE** ..... 24

**WEIGHT DISTRIBUTION** ..... 24

**Weight Distribution Formulas** ..... 26

- Basic Formulas ..... 26

**Weight Distribution Formulas in Words** ..... 27

**Recommended Weight Distribution % of Gross Vehicle Weight by Axle** ..... 30

**TRAILER WEIGHT** ..... **30**
Payload at Kingpin ..... 31
Payload at Rear Tandem ..... 31

**Performance Calculations** ..... **32**
Speed Formula ..... 32
Grade Horsepower Formula ..... 32
Air Resistance Horsepower Formula ..... 32
Engine Horsepower Formula ..... 33
Gradeability Formula ..... 33
Startability Formula ..... 34
Vertical Center of Gravity Formula ..... 34
Horizontal Center of Gravity Formula ..... 35

**INTERSTATE HIGHWAY SYSTEM LIMITS** ..... **36**
Bridge Gross Weight Formula ..... 36
Bridge Formula Definitions ..... 36
Consecutive Axle Weight ..... 37
Exception to the Bridge Formula ..... 37
Other Federal Provisions ..... 37

**FEDERAL BRIDGE FORMULA TABLE** ..... **38**

# W3500/W4500 DIESEL




**SPECIFICATIONS** . . . . . 1

**VEHICLE WEIGHTS, DIMENSIONS AND RATINGS** . . . . . 2

- Variable Chassis Dimensions . . . . . 3
- Dimension Constants . . . . . 3
- 12,000 lb. GVWR Manual Transmission Model . . . . . 3
- 14,500 lb. GVWR Manual Transmission Model . . . . . 3
- 12,000 lb. GVWR with Aisin Automatic Transmission Model . . . . . 3
- 14,500 lb. GVWR with Aisin Automatic Transmission Model . . . . . 3
- Vehicle Weight Limits: . . . . . 3
- Model Descriptions . . . . . 3

**FRAME & CROSSMEMBER SPECIFICATIONS** . . . . . 4

**FRAME CHART** . . . . . 5

**AUXILIARY VIEWS** . . . . . 6

**BODY BUILDER WEIGHT INFORMATION CHART** . . . . . 7

- Cab Tilt . . . . . 7
- Center of Gravity . . . . . 7

**FRONT AXLE CHART** . . . . . 8

**REAR AXLE CHART** . . . . . 9

- Definitions . . . . . 10
- Formulas for Calculating Rear Width and Height Dimensions . . . . . 10

**SUSPENSION DEFLECTION CHARTS** . . . . . 11

**TIRE AND DISC WHEEL CHART** . . . . . 12

- Tire . . . . . 12
- Disc Wheel . . . . . 12

**PROPELLER SHAFT** . . . . . 13

**PTO LOCATION, DRIVE GEAR AND OPENING INFORMATION** . . . . 15

- Opening Diagram . . . . . 16

**BRAKE SYSTEM SCHEMATIC** . . . . . 17

- Vacuum Over Hydraulic . . . . . 17

**1999 MODEL DIESEL FUEL FILLER** . . . . . 18

- Installation Instructions . . . . . 18

**INSTALLATION DRAWINGS OF FUEL FILLER HOSE** . . . . . 19

- Drawing #1 . . . . . 19
- Drawing #2 . . . . . 19
- Drawing #3 . . . . . 20
- Drawing #4 . . . . . 20
- Drawing #5 . . . . . 21
- Drawing #3 . . . . . 21

# W3500/W4500 GAS




**SPECIFICATIONS** . . . . . 1

**VEHICLE WEIGHTS, DIMENSIONS AND RATINGS** . . . . . 2

- Variable Chassis Dimensions . . . . . 3
- Dimension Constants 11,050 GVW . . . . . 3
- 11,050 lb. GVWR with 4L80-E Hydra-Matic Transmission Model Federal . . . . . 3
- 11,050 lb. GVWR with 4L80-E Hydra-Matic Transmission Model California . . . . . 3
- Dimension Constants 14,050 GVW . . . . . 3
- 14,050 lb. GVWR with 4L80-E Hydra-Matic Transmission Model California/Federal . . . . . 3
- Vehicle Weight Limits: . . . . . 3

**FRAME & CROSSMEMBER SPECIFICATIONS** . . . . . 4

**FRAME CHART** . . . . . 5

**AUXILIARY VIEWS** . . . . . 6

**BODY BUILDER WEIGHT INFORMATION CHART** . . . . . 7

- Cab Tilt . . . . . 7
- Center of Gravity . . . . . 7

**FRONT AXLE CHART** . . . . . 8

**REAR AXLE CHART** . . . . . 9

- Definitions . . . . . 10
- Formulas for Calculating Rear Width and Height Dimensions . . . . . 10

**SUSPENSION DEFLECTION CHARTS FOR W3500** . . . . . 11

**SUSPENSION DEFLECTION CHARTS FOR W4500** . . . . . 12

**TIRE AND DISC WHEEL CHART** . . . . . 13

- Tire . . . . . 13
- Disc Wheel . . . . . 13

**PROPELLER SHAFT** . . . . . 14

**BRAKE SYSTEM SCHEMATIC** . . . . . 16

- Vacuum Over Hydraulic . . . . . 16

**1999 MODEL GASOLINE FUEL FILLER** . . . . . 17

- Installation Instructions (Revised) . . . . . 17
- Gas Filler Neck Installation (Rear View) 96” Wide Body . . . . . 17

**GAS FILLER NECK INSTALLATION (TOP VIEW) 96” WIDE BODY** . 18

- Gas Filler Neck Installation (Top View) 96” Wide Body . . . . . 18

# W5500 DIESEL




**SPECIFICATIONS** ..... 1

**VEHICLE WEIGHTS, DIMENSIONS AND RATINGS** ..... 2

- Variable Chassis Dimensions ..... 3
- Dimension Constants ..... 3
- 16,500 lb. GVWR Manual Transmission Model ..... 3
- 16,500 lb. GVWR Automatic Transmission Model ..... 3
- Vehicle Weight Limits: ..... 3
- Model Descriptions ..... 3

**FRAME & CROSSMEMBER SPECIFICATIONS** ..... 4

**FRAME CHART** ..... 5

**AUXILIARY VIEWS** ..... 6

**BODY BUILDER WEIGHT INFORMATION CHART** ..... 7

- Cab Tilt ..... 7
- Center of Gravity ..... 7

**FRONT AXLE CHART** ..... 8

**REAR AXLE CHART** ..... 9

- Definitions ..... 10
- Formulas for Calculating Rear Width and Height Dimensions ..... 10

**SUSPENSION DEFLECTION CHARTS** ..... 11

**TIRE AND DISC WHEEL CHART** ..... 12

- Tire ..... 12
- Disc Wheel ..... 12

**PROPELLER SHAFT** ..... 13

**PTO LOCATION, DRIVE GEAR AND OPENING INFORMATION** ..... 15

- Opening Diagram ..... 16

**BRAKE SYSTEM SCHEMATIC** ..... 17

- Vacuum Over Hydraulic ..... 17

# ELECTRICAL–DIESEL




**SYMBOLS** . . . . . 1

**ABBREVIATIONS** . . . . . 2

**WIRING** . . . . . 3

- Wire Color . . . . . 3
- Distinction of Circuit by Wire Base Color . . . . . 3
- Wire Size . . . . . 3

**GROUNDING POINT LOCATION** . . . . . 4

**REFERENCE TABLE OF GROUNDING POINT** . . . . . 5

**BODY ROOM LIGHT, ID & MARKER LAMP CONNECTOR LOCATION** . . . . . 6

**CIRCUIT DIAGRAM BODY ROOM LIGHT** . . . . . 7

**CIRCUIT DIAGRAM BODY ID & MARKER LIGHTS** . . . . . 8

**FUSE AND FUSIBLE LINK LOCATION** . . . . . 9

- Fuse Label . . . . . 9

**FUSE BLOCK CIRCUIT** . . . . . 10

**REFERENCE TABLE OF FUSE** . . . . . 11

**RELAY LOCATION** . . . . . 12

**RELAY LIST** . . . . . 13

**CIRCUIT DIAGRAM AUXILIARY POWER SOURCE** . . . . . 14

**CIRCUIT DIAGRAM ACCESSORY WIRING** . . . . . 15

**CIRCUIT DIAGRAM HORN AND BACK–UP LIGHT** . . . . . 16

**CIRCUIT DIAGRAM ENGINE STOP MOTOR** . . . . . 17

**CIRCUIT DIAGRAM TURN, HAZARD & STOP LAMPS** . . . . . 18

**CIRCUIT DIAGRAM INSTRUMENT PANEL** . . . . . 19

**FUEL TANK SENDING UNIT RESISTANCE** . . . . . 20

# ELECTRICAL–GAS




**SYMBOLS** . . . . . 1

**ABBREVIATIONS** . . . . . 2

**WIRING** . . . . . 3

- Wire Color . . . . . 3
- Distinction of Circuit by Wire Base Color . . . . . 3
- Wire Size . . . . . 3

**GROUNDING POINT LOCATION** . . . . . 4

**REFERENCE TABLE OF GROUNDING POINT** . . . . . 5

**BODY ROOM LIGHT, ID & MARKER LAMP CONNECTOR LOCATION** . . . . . 6

**CIRCUIT DIAGRAM BODY ROOM LIGHT** . . . . . 7

**CIRCUIT DIAGRAM BODY ID & MARKER LAMPS** . . . . . 8

**FUSE AND FUSIBLE LINK LOCATION** . . . . . 9

- Fuse Label . . . . . 9

**FUSE BLOCK CIRCUIT** . . . . . 10

**FUSIBLE LINK** . . . . . 11

**REFERENCE TABLE OF FUSE** . . . . . 12

**RELAY LOCATION** . . . . . 13

**RELAY LIST** . . . . . 14

**CIRCUIT DIAGRAM AUXILIARY POWER SOURCE** . . . . . 15

**CIRCUIT DIAGRAM ACCESSORY WIRING** . . . . . 16

**CIRCUIT DIAGRAM HORN & BACK–UP LIGHT** . . . . . 17

**CIRCUIT DIAGRAM TURN SIGNAL, HAZARD & STOP LAMPS** . . . . 18

**CIRCUIT DIAGRAM INSTRUMENT PANEL** . . . . . 19

**FUEL TANK SENDING UNIT RESISTANCE** . . . . . 20

**F–SERIES RELAY LOCATION** . . . . . 21

**DEDICATED BODY BUILDER ELECTRICAL CIRCUITS BEHIND ENGINE FOR F–SERIES** . . . . . 22

**DEDICATED BODY BUILDER ELECTRICAL CIRCUITS BEHIND ENGINE FOR F–SERIES** . . . . . 23

- Under the Cab Connection . . . . . 23

**BODY–CHASSIS ELECTRICAL CONNECTORS** . . . . . 24

**WIRING DIAGRAM BODY MOUNTING CIRCUITS** . . . . . 25

**BODY BUILDERS HARNESS ELECTRICAL COMPONENT LOCATION TABLE** . . . . . 26

- Body Builder Inline Connector . . . . . 26